

Music Factory Veranstaltungstechnik

DMX Kanalübersicht – LED Floorspot Akku 6x18W RGBAW

2CH Modus

Kanal	Funktion
CH1	0–255 Gesamt-Dimmer
CH2	0–10 Aus 11–255 Farbtemperatur 2000K–4400K (laut Tabelle)

6CH Modus

Kanal	Funktion
CH1	0–255 Rot
CH2	0–255 Grün
CH3	0–255 Blau
CH4	0–255 Weiß
CH5	0–255 Gelb
CH6	0–255 Lila

8CH Modus

Kanal	Funktion
CH1	0–255 Gesamt-Dimmer
CH2	0–9 Aus 10–255 Strobe
CH3	0–255 Rot
CH4	0–255 Grün
CH5	0–255 Blau
CH6	0–255 Weiß
CH7	0–255 Gelb
CH8	0–255 Lila

11CH Modus

Kanal	Funktion
CH1	0–255 Gesamt-Dimmer
CH2	0–255 Rot
CH3	0–255 Grün

CH4	0–255 Blau
CH5	0–255 Weiß
CH6	0–255 Gelb
CH7	0–255 Lila
CH8	0–9 Aus 10–255 Strobe
CH9	Farbtemperatur 2000K–10000K (laut DMX-Wertetabelle)
CH10	Programme: Static / Jump / Gradient / Voice Control
CH11	0–255 Geschwindigkeit